

Assembly Instructions for Light Kit

The light kit will bolt onto the A-Frame of the mount for the tie rod. See Detail A. Using the 6" long 1/2" bolts, attach the mount to the A frame with the included bolt plate. The light mount can be adjusted up and down within the A frame for best fit for the customer. Once the mounts are adjusted to the desired height, tighten the bolts in place. Repeat for the other side.

Parts List

| ITEM | QTY | PART NUMBER | DESCRIPTION |
|------|-----|-------------|--------------------------------|
| 1 | 1 | HT-B10T | B10 Step up Bar with Tierod |
| 2 | 2 | HT-OP22-P02 | Light Mount Bracket |
| 3 | 2 | HT-OP22-P01 | Light Mount Bracket Bolt Plate |
| 4 | 8 | N1/2N | Hex Nut |
| 5 | 8 | W1/2F | Flat Washer |
| 6 | 8 | W1/2L | Lock Washer |
| 7 | 8 | B1/2x6.0 | Hex Bolt |

