



Intercomp Instructions for Auto Dispense

Start Auto Dispense

1. Make sure Toggle switch is set to Auto
2. Press UNLOAD
3. Most recent target weight is displayed. Default is 100 lbs.
4. If correct target weight is displayed press enter.
 - a. If you need to change target weight enter in new weight with numeric keypad and press ENTER
5. PRACT IS BRIEFLY DISPLAYED before showing the most RECENT PRACT setting (DEFAULT IS 20 lbs.)
 - a. If correct PRACT IS DISPLAYED PRESS ENTER
 - b. If you need to change target weight enter in new weight with numeric keypad and press ENTER